

ContiTech ScrewKits

- › Screw kits for ContiTech and PHOENIX air springs
- › 100% fit
- › Clearly referenced
- › High quality content
- › Approved to ISO standards
- › Uniform packaging for optimized logistics



Kit	Kit No.	Vehicle	Application	Fits
K001	52726	Trailer	SAF	4004 N P05, 4023 N P03, 4810 N P05, 912 N P01, 1 D 28 A-10, 1 D 28 A-13, 1 D 28 B-10, 1 D 28 B-10 NP, 1 D 28 D-10, 1 DK 22 E-5, 1 DK 22 E-5 NP
K002	52727	Trailer	Hendrickson, Meritor, ROR, SAF, Weweler	4023 N P08, 4028 N P05, 4810 N P06, 810 MB, 813 MB, 912 N P02, 1 D 28 A-2, 1 D 28 A-5 NP, 1 D 28 B-2, 1 D 28 B-5 NP, 1 D 28 B-12, 1 D 28 C-12, 1 D 28 D-2, 1 D 28 G-26
K003	52728	Truck	Scania	4813 N P07, 1 D 28 B-9
K004	52729	Truck	Scania 4, Scania R	4913 N P02, 4913 N P04, 6700 N P01, 6700 N P02, 1 D 28 H-16, 1 D 28 H-16 NP
K005	52730	Truck	Volvo	6600 N P02, 6605 N P01, 6606 N P01, 6606 N P02, 6607 N P01, 6608 N P01, 1 DF 17 A-1, 1 DF 17 B-1, 1 DF 20 D-1, 1 DF 20 E-1
K006	52731	Truck	Volvo	4420 N P01, 4713 N P02, 4713 N P04, 4718 N P01, 4718 N P02, 6609 N P01, 6610 N P01, 6612 N P01, 6613 N P01, 1 DF 22 C-1
K007	52732	Bus	Solaris	1 DF 25 A-1, 1 DF 25 A-1 NP, 1 DF 25 A-2, 1 DF 25 A-7, 1 DF 25 A-8, 1 DF 25 A-20, 1 DF 25 A-21
K008	52733	Bus, Truck	VDL Bus, DAF Truck	836 M, 836 M K1, 836 M K11, 836 M K7, 836 M2, 836 M2 K1, 836 MB, 836 MB K4, 836 MB K6, 836 N P05, 836 N P06, 836 N P09, 836 N P10, 836 N P14, 836 N P16, 887 M, 887 M K1, 887 M K2, 887 M K3, 887 M K4, 887 N P03, 887 N P04, 887 N P06, 887 N P09, 889 M, 889 M K2, 1 DF 25-11, 1 DF 25-12, 1 DF 25-13, 1 DF 25-14, 1 DF 25-15

Kit	Kit No.	Vehicle	Application	Fits
K009	52734	Trailer	Schmitz, Weweler	4157 N P06, 4158 N P03, 1 DK 20 A-1, 1 DK 20 B-1
K010	52735	Trailer	Acerbi, Fruehauf, SMB	4157 N P10, 1 DK 20 A-51
K011	52736	Trailer	Daimler TAS, ROR, Schmitz, Weweler, Holland Hitch	4157 N P14, 1 DK 20 C-54, 1 DK 21 A-4, 1 DK 28 F-3
K012	52737	Trailer	BPW (w/o piston)	881 MB, 940 MB, 941 MB, 942 MB, 4881 N P02, 1 DK 21, 1 DK 21 K, 1 DK 32, 1 DK 32 K, 1 DK 32 L
K013	52738	Trailer	SAF	4022 N P05, 1 DK 22 E-11, 1 DK 22 E-13, 1 DK 22 E-14
K014	52739	Trailer	SAF	4004 N P03, 4022 N P03, 1 D 28 B-11, 1 DK 22 E-8, 1 DK 22 E-9, 1 DK 22 E-9 NP
K015	52740	Trailer	Fruehauf, SMB, Hendrickson, Weweler, SAMRO, Montenegro	4156 N P07, 4156 N P15, 4159 N P03, 4159 N P14, 1 DK 21 B-4, 1 DK 23 K-1, 1 DK 23 K-28, 1 DK 23 L-27
K016	52741	Trailer	Cardi, Fruehauf, SAMRO, SMB	4159 N P09, 1 DK 23 L-9131
K017	52742	Bus	Bova, Den Oudsten	1 E 26-1
K018	52743	Truck	Renault, Volvo	4911 N P03, 4911 N P04, 4911 N P06, 4912 N P07, 4912 N P08, 4912 N P10, 4912 N P13, 4915 N P03, 4915 N P06, 1 DK 28 F-4, 1 DK 28 F-5
K019	52744	Trailer	Kässbohrer	1 DK 32 E-4
K020	52745	Bus	Ikarus, Roman	1 E 26-5

Kit	Kit No.	Vehicle	Application	Fits
K021	52746	Truck, (Bus)	Mercedes Actros	4183 N3, 4183 N P23, 4183 N P25, 4185 N, 4185 N P21, 4186 N3, 4186 N P23, 4187 N3, 4187 N P21, 4187 N P23, 4390 N1, 4390 N P01, 4390 N P04, 4390 N P21, 4390 N P24, 4391 N1, 4391 N P01, 4391 N P21, 4644 N, 4644 N P02, 4644 N P22, 4737 N, 4737 N P21, 4737 N P22, 4737 N P25, 4737 N P26, 4757 N1, 4757 N2, 4757 N P21, 4757 N P29, 4758 N, 4758 N P21, 4758 N P23, 4759 N, 4759 N P21, 4838 N P21, 4838 N P22, 4838 N P23, 644 N P21, 1 KF 21-1, 1 KF 21-1 NP, 1 KF 21-2, 1 KF 21-2 NP, 1 KF 21-21, 1 KF 21-22, 1 KF 24-1, 1 KF 24-1 NP, 1 KF 24-2 NP, 1 KF 24-9, 1 KF 24-21, 1 KF 24-29, 1 KF 32-23, 1 KF 32-23 NP
K022	52747	Bus	Irisbus, Iveco Bus, Heuliez	1415 N P01, 1415 N P02, 1782 N1 P01, 1782 N1 P02, 1924 N1 P05, 2 F 18-1, 1 E 23 A-1, 1 E 23 B-1
K023	52748	Trailer	Convoluted Air Springs 1/4" M10	FD 200-19 1/4 M10, FD 200-19 P04, FD 200-22 1/4 M10, FD 200-25 1/4 M10, FD 200-25 P02, SP 2 B 12 R, SP 2 B 12 R-5, SP 2 B 12 R-A-3, SP 2 B 12 R-A-10
K024	52749	Bus	Volvo	6600 N P01, 6604 N P01, 6604 N P03, 1 DF 17-1
K025	52750	Trailer	Meritor, ROR, Weweler	4157 N P05, 4157 N P09, 1 DK 21 A-3, 1 DK 21 A-31
K026	52751	Trailer	BPW	4960 N P02, 1 DK 21 K-3

Kit	Kit No.	Vehicle	Application	Fits
K027	52752	Trailer	Daimler TAS	1 DK 25-1
K028	52753	Trailer	Schmitz, Weweler	4028 N P02, 1 D 28 F-1, 1 D 28 F-5
K029	52754	Trailer	BPW (complete)	881 MB, 881 MB P30, 940 MB, 940 MB P30, 941 MB, 941 MB P30, 942 MB, 951 MB, 4881 N P02, 4881 N P30, 4940 N P02, 4941 N P02, 4942 N P02, 4961 N P02, 4962 N P02, 4963 N P01, 1 DK 21, 1 DK 21-1, 1 DK 21-2, 1 DK 21 K, 1 DK 21 K-1, 1 DK 21 K-2, 1 DK 32, 1 DK 32-1, 1 DK 32-2, 1 DK 32 K, 1 DK 32 K-1, 1 DK 32 K-2, 1 DK 32 L, 1 DK 32 L-1
K030	52755	Trailer	Bertoja, Fruehauf, SMB	4156 N P09, 4157 N P03, 4159 N P07, 1 DK 23 K-54, 1 DK 23 L-25
K031	53106	Bus, Truck	Scania	1 DF 20 A-1, 1 DF 20 A-2, 1 DF 20 A-3, 1 DF 20 A-4, 1 DF 20 A-5, 1 DF 20 A-6, 1 DF 20 A-7, 1 DF 20 A-8, 1 DF 20 A-9, 1 DF 20 A-10, 1 DF 20 C-1, 1 DF 20 C-2, 1 DF 20 C-3, 1 DF 23 A-1, 1 DF 23 A-2, 1 DF 23 A-3, 1 DF 23 B-1, 1 DF 23 B-2, 1 DF 23 B-3, 1 DF 23 B-4, 1 DF 23 B-5, 1 DF 23 C-1, 1 DF 23 D-1
K032	53107	Truck	MAN	4705 N1 P03, 4705 N1 P04, 4883 N1 P06
K033	53108	Truck	MAN	4862 N1 P02, 4882 N1 P05, 4884 N1 P06, 4884 N1 P07, 4884 N1 P09, 4885 N1 P02, 1 DF 16-2, 1 DF 19 B-1
K034	53110	Truck	MAN	4916 N1 P07
K035	53111	Bus, Truck	Volvo	6602 N P01, 6602 N P02
NEW K037	53782	Trailer	Schmitz, Weweler	1 DK 23 L-1

Additional ScrewKits

Kit	Kit No.	Vehicle	Application	Fits	Info
K036	53112	Truck	Mercedes	4183 N1, 4183 N4, 4183 N P24, 4183 N P26, 4186 N4, 4186 N P24, 4187 N2, 4187 N4, 4187 N P22, 4187 N P24, 4390 N2, 4390 N P02, 4390 N P03, 4390 N P22, 4390 N P23, 4391 N2, 4391 N P02, 4391 N P22	With blind plug for sensor inlet
K230	53113	Truck	Mercedes	Actros <- 2005	Adapter Voss 232 -> 230



The content of this publication is not legally binding and is provided as information only. The trademarks displayed in this publication are the property of Continental AG and/or its affiliates. Copyright © 2016 ContiTech AG. All rights reserved. For complete information go to: www.contitech.de/disc_l_en

