

Technical News

Product News

Servicearticle - Screwkits



Pic.1: Screwkit for bus & truck applications





Pic.2: Screwkit for trailer applications

ContiTech Air Spring Systems is now offering screw kits for nearly 200 fast-movers of our ContiTech and Phoenix range. The packages include all relevant mounting parts for your individual application.

Facts:

- Screwkits will not be sold separately – only in combination with the corresponding air spring
- Easy identification of appropriate air spring on the box (sticker)
- 30 different kits for nearly 200 air spring systems

Our recommendations:

- Easy identify the right kit for your air spring system by clear signs in our product catalogue (→ see: )
- Please consider the recommended tightening torques for all screw fittings – details to be found in our actual product catalogues (→ see: )
- Here you will find all relevant news about air spring systems:
www.contitech.de/airspring-aftermarket

Status: September 2010

ContiTech Luftfedersysteme GmbH
Philipsbornstraße 1, D-30165 Hannover
Techn. Hotline +49 (0)511 938 -5268
E-Mail: ingo.rosenau@as.contitech.de
www.contitech.de/airspring-aftermarket

 
CONTITECH

Product News

Servicearticle – Screwkits: Fitment-Guide

Phoenix		Screw-Kit	
Type	art.no.	Type	art.no.
1 D 28 A-10	50 857	K001	52 726
1 D 28 A-2	50 855	K002	52 727
1 D 28 B-10	50 867	K001	52 726
1 D 28 B-2	50 861	K002	52 727
1 D 28 B-9	50 866	K003	52 728
1 D 28 C-12	50 870	K002	52 727
1 D 28 D-10	50 874	K001	52 726
1 D 28 F-1	50 875	K028	52 753
1 D 28 H-16	50 883	K004	52 729
1 DF 17 A-1	52 325	K005	52 730
1 DF 17 B-1	52 326	K005	52 730
1 DF 17-1	52 324	K024	52 749
1 DF 20 D-1	52 327	K005	52 730
1 DF 20 E-1	52 328	K005	52 730
1 DF 22 C-1	50 978	K006	52 731
1 DF 25 A-1	50 988	K007	52 732
1 DF 25 A-2	50 989	K007	52 732
1 DF 25-11	50 982	K008	52 733
1 DF 25-12	50 983	K008	52 733
1 DF 25-13	50 984	K008	52 733
1 DF 25-14	50 985	K008	52 733
1 DF 25-15	50 986	K008	52 733
1 DK 20 A-1	50 907	K009	52 734
1 DK 20 A-51	50 908	K010	52 735
1 DK 20 B-1	50 910	K009	52 734
1 DK 20 C-54	50 913	K011	52 736
1 DK 21	50 915	K012	52 737
1 DK 21 A-3	50 916	K025	52 750
1 DK 21 A-31	50 919	K025	52 750
1 DK 21 A-4	50 917	K011	52 736
1 DK 21 A-9	50 918	K025	52 750
1 DK 21 B-4	50 920	K015	52 740
1 DK 21 K	50 922	K012	52 737
1 DK 21 K-1	51 876	K029	52 754
1 DK 21 K-2	52 656	K029	52 754
1 DK 21 K-3	50 923	K026	52 751
1 DK 21-1	51 875	K029	52 754
1 DK 21-2	52 653	K029	52 754
1 DK 22 E-11	51 687	K013	52 738
1 DK 22 E-5	50 928	K001	52 726

Phoenix		Screw-Kit	
Type	art.no.	Type	art.no.
1 DK 22 E-6	50 925	K001	52 726
1 DK 22 E-8	50 926	K014	52 739
1 DK 22 E-9	50 927	K014	52 739
1 DK 23 K-1	52 201	K015	52 740
1 DK 23 K-28	50 849	K015	52 740
1 DK 23 L-1	52 006	K030	52 755
1 DK 23 L-25	50 958	K030	52 740
1 DK 23 L-27	50 959	K015	52 740
1 DK 23 L-9131	50 961	K016	52 741
1 DK 25-1	52 553	K027	52 752
1 DK 28 F-3	50 877	K011	52 736
1 DK 28 F-4	50 971	K018	52 743
1 DK 32	50 972	K012	52 737
1 DK 32 E-4	50 973	K019	52 744
1 DK 32 K	50 974	K012	52 737
1 DK 32 K-1	51 878	K029	52 754
1 DK 32 K-2	52 658	K029	52 754
1 DK 32 L	50 975	K012	52 737
1 DK 32-1	51 877	K029	52 754
1 DK 32-2	52 657	K029	52 754
1 E 26-1	50 897	K017	52 742
1 E 26-5	50 901	K020	52 745
1 KF 21-1	50 991	K021	52 746
1 KF 21-2	50 992	K021	52 746
1 KF 21-21	52 003	K021	52 746
1 KF 21-22	52 004	K021	52 746
2 F 18-1	50 976	K022	52 747
SP 2 B 12 R 1/4 M10	50 815	K023	52 748
SP 2 B 12 R-5	50 817	K023	52 748
SP 2 B 12 R-A-3	50 821	K023	52 748

ContiTech Luftfedersysteme GmbH
 Philipsbornstraße 1, D-30165 Hannover
 Techn. Hotline +49 (0)511 938 -5268
 E-Mail: ingo.rosenau@as.contitech.de
 www.contitech.de/airspring-aftermarket

Continental 
CONTITECH

Product News

Servicearticle – Screwkits: Fitment-Guide

ContiTech		Screw-Kit	
Type	art.no.	Type	art.no.
0195 N P01	62 861	K004	52 729
1113 N P01	62 862	K004	52 729
1415 N P01	62 794	K022	52 747
1415 N P02	62 795	K022	52 747
1782 N1 P01	62 700	K022	52 747
1924 N1 P05	60 254	K022	52 747
1924 N1 P08	62 421	K022	52 747
4004 N P03	67 213	K014	52 739
4004 N P 05	67 747	K001	52 726
4022 N P03	52 541	K014	52 739
4022 N P05	52 542	K013	52 738
4023 N P03	67 221	K001	52 726
4023 N P07	67 745	K028	52 753
4023 N P08	67 746	K002	52 727
4028 N P02	52 571	K001	52 753
4028 N P05	52 572	K002	52 727
4156 N P07	52 567	K015	52 740
4156 N P09	52 568	K025	52 750
4156 N P15	50 654	K015	52 740
4157 N P03	66 493	K025	52 750
4157 N P04	66 494	K011	52 736
4157 N P05	66 495	K025	52 750
4157 N P06	66 496	K009	52 734
4157 N P08	66 497	K010	52 735
4157 N P09	66 499	K025	52 750
4157 N P10	66 500	K010	52 735
4158 N P03	52 576	K009	52 734
4159 N P03	52 562	K015	52 740
4159 N P07	52 564	K015	52 740
4159 N P09	50 668	K016	52 741
4159 N P14	50 652	K015	52 740
4183 N P23	65 915	K021	52 746
4183 N P24	63 622	K021	52 746
4185 N P01	62 621	K021	52 746
4185 N P21	65 942	K021	52 746
4187 N P01	65 714	K021	52 746
4187 N P21	65 715	K021	52 746
4187 N P22	65 913	K021	52 746
4390 N P01	60 234	K021	52 746
4390 N P02	60 235	K021	52 746

ContiTech		Screw-Kit	
Type	art.no.	Type	art.no.
4718 N P01	62 623	K006	52 731
4810 N P05	61 162	K001	52 726
4813 N P07	52 570	K003	52 728
4881 N P02	67 251	K012	52 737
4911 N P03	67 718	K018	52 743
4911 N P04	67 719	K018	52 743
4911 N P06	67 741	K018	52 743
4912 N P07	67 252	K018	52 743
4912 N P10	67 720	K018	52 743
4912 N P13	67 834	K018	52 743
4913 N P02	67 254	K004	52 729
4915 N P03	67 721	K018	52 743
4915 N P06	67 722	K018	52 743
4960 N P02	67 259	K026	52 751
6609 N P01	63 372	K006	52 731
661 N P02	60 025	K022	52 747
769 M	67 175	K022	52 747
769 MB	67 177	K022	52 747
782 MB-3	2686 082 000	K022	52 747
782 N P04	2686 089 000	K022	52 747
810 MB	52 573	K002	52 727
813 MB	67 193	K002	52 727
817 MB	2686 005 000	K022	52 747
819 MB	67 196	K022	52 747
836 M K1	60 209	K008	52 733
836 M K7	60 278	K008	52 733
836 M K11	t.b.d.	K008	52 733
836 M2 K1	60 210	K008	52 733
836 MB K4	60 276	K008	52 733
836 MB K6	60 277	K008	52 733
876 MB	2686 051 000	K022	52 747
881 MB	67 197	K012	52 737
887 M K1	60 211	K008	52 733
887 M K2	t.b.d.	K008	52 733
887 M K3	t.b.d.	K008	52 733
887 M K4	t.b.d.	K008	52 733
887 N P04	63 276	K008	52 733
889 M K2	67 200	K008	52 733
912 N P01	67 201	K001	52 726
912 N P02	67 202	K002	52 727

ContiTech Luftfedersysteme GmbH
 Philipsbornstraße 1, D-30165 Hannover
 Techn. Hotline +49 (0)511 938 -5268
 E-Mail: ingo.rosenau@as.contitech.de
 www.contitech.de/airspring-aftermarket



Product News

Servicearticle – Screwkits: Fitment-Guide

ContiTech		Screw-Kit	
Type	art.no.	Type	art.no.
4390 N P03	60 236	K021	52 746
4390 N P04	60 237	K021	52 746
4390 N P21	62 424	K021	52 746
4390 N P22	62 425	K021	52 746
4390 N P23	62 426	K021	52 746
4390 N P24	62 427	K021	52 746
4391 N P01	62 618	K021	52 746
4391 N P02	62 619	K021	52 746
4391 N P21	63 716	K021	52 746
4391 N P22	63 717	K021	52 746
4420 N P01	62 625	K006	52 731
4713 N P02	60 238	K006	52 731

ContiTech		Screw-Kit	
Type	art.no.	Type	art.no.
921 M	67 203	K022	52 747
921 MB	67 204	K022	52 747
936 MB	2686 040 000	K022	52 747
940 MB	67 205	K012	52 737
941 MB	67 207	K012	52 737
942 MB	67 209	K012	52 737
FD 200-19 1/4 M10	52 054	K023	52 748
FD 200-19 P04	52 056	K023	52 748
FD 200-22 1/4 M10	62 921	K023	52 748
FD 200-25 1/4 M10	62 892	K023	52 748
FD 200-25 P02	66 476	K023	52 748

ContiTech Luftfedersysteme GmbH
 Philipsbornstraße 1, D-30165 Hannover
 Techn. Hotline +49 (0)511 938 -5268
 E-Mail: ingo.rosenau@as.contitech.de
 www.contitech.de/airspring-aftermarket

Continental 
CONTITECH